



General Rules for Custom Linings Coating Applications

- 1. Material in Drums, Warm and Mixed as Required**
- 2. Main Machine Heated Up**
- 3. Gun Serviced and Clean**
- 4. Purge Spray Hose Lines**
- 5. Application Surface is Dry and Cleaned with Blue Paper Towels and Acetone Only**
- 6. Once you start spraying, Complete Job With Out Interruption**
- 7. Pack Gun with White Grease when Done Spraying**
- 8. Machine Pumps Clean and CU6'd**

Technical Support: 877-POLYUREA