



## Truck Prep Process

1. Truck in Booth
  - Curtain between cab and bed (2 sheets paper)
  - Cover cab (single sheet of cab plastic)
2. Clean and dry bed with acetone
3. Tape tailgate
  - Wire tape edge
  - Tape and plastic/paper back of gate
  - Remove gate
  - Tape sides of gate
  - Remove hardware
  - Sand
4. Use wire tape and masking tape as required to mask back and sides of bed
5. Tape bed plastic to bed
6. Sand all edges/back of bed, sides of bed and floor
7. Sweep or blow out bed and tailgate
8. Wipe with acetone
9. See Spray Process