



Truck Spray Process

1. Ensure equipment is warmed up, Check spray pattern, Check machine, Spray sample, reset counter
2. Wipe tailgate with acetone and spray immediately. Spray tailgate, tape lines first, then standing in center of gate apply total 50 strokes and texture
3. Wipe bed with acetone and spray immediately. Standing back of bed, spray bed at tape lines
4. Spray all edges and corners and under bed rails
5. Spray area under back window
6. From each side:
 - From a ladder or step, spray bed floor (3 times)
 - From the floor, spray edges and corners (3 times)
 - From the floor, spray side of bed (3 times)
7. Check counter/Repeat steps 4,5,6 as required
8. Texture

NOTE: Count to 3 between each texture pass

 - Sides (Rapidly Move gun across bedside) 6-9 times
 - Back (Straight down motion) 3-6 times

Target 250 Strokes