



## End of Day/Gun Service/P2 Only

**Use this at the end of the day to retract the pistons on your machine and service your gun**

- 1. Turn air motor switch to retract**
- 2. Trigger gun to bring material pistons to retract position**
- 3. Bring material pressures to 500-1000 psi per the gauges**
- 4. Turn off material ball valves on gun and purge out material with the trigger on the gun**
- 5. Place spray gun in vise by handle**
- 6. Let air purge out of nose of gun for 15 seconds**
- 7. Apply white lithium grease to gun via grease zert on top of gun**
- 8. Allow grease to shoot out of nose of gun under air pressure**
- 9. Turn off air valve on gun**
- 10. Turn off air supply and electricity to the spray machine**
- 11. Disconnect air supply from red and blue drums**
- 12. Apply CU-6 to material high pressure piston seals**
- 13. Wipe exterior of gun clean**
- 14. Service gun on next business day as required prior to spraying**

**Do not disassemble gun at the end of the day to soak or clean.**

**Always clean gun prior to the first spray job of the day if required.**