



Gun Cleaning Procedure

Probler 2 gun only

Note: Use this procedure just before spraying any job

1. Ensure material ball valves are turned off
2. Clean exterior of gun
3. Remove and clean (soak if required in CU-6) air cap, mixing chamber and chamber housing.

Note: Chamber housing is clean when mixing chamber falls through

Note: Clean all parts with Berrymans Carb clean and dry before reassembly

Caution: Razor blades are very sharp and can cause serious injury

4. Ensure mixing chamber is clean and undamaged. Carefully use a new razorblade to ensure there is no residue build up on mixing chamber.
5. Disassemble side blocks and clean all parts separately. Replace any worn or damaged parts.
6. Ensure side block seals are undamaged and have spring to them (black buttons)
7. Apply white grease to side block mating ports prior to reassembly
8. Purge grease from gun and test prior to spraying application.

Please refer to your Probler Gun Operation Manual (available on-line) for illustrated parts break down and additional technical information or call your Custom Linings Representative.